

## Camcorder Belt Kits (CKT)

### CKT1

**SCA4.5** Belt  
**SCB8.1** Belt

Used in: Magnavox,  
Panasonic, Quasar, Sylvania  
and other camcorders.

### CKT2

**SCQ2.5** Belt  
**SCA4.2** Belt

Used in: Magnavox,  
Panasonic, Quasar, Sylvania  
and other camcorders.

### CKT3

**SCQ4.6** Belt  
**SCB8.1** Belt

Used in: Panasonic  
camcorders.

### CKT4

**SCQ3.2** Belt  
**SCA8.6** Belt

Used in: Sharp camcorders.

### Camcorder Zoom Belt!

This belt is used for the zoom  
function in many JVC and  
Minolta camcorders.

P/N:	IC	C/S	Wall
<b>SCY1.2</b>	1.20	.030	.030

## CKT Cross Reference

Mfr./Model#	CKT Kit#	Mfr./Model#	CKT Kit#	Mfr./Model#	CKT Kit#	Mfr./Model#	CKT Kit#	Mfr./Model#	CKT Kit#
<b>GENERALELECTRIC</b>		CVK-315	CKT2	PV-300D	CKT1	<b>PHILIPS</b>		<b>SHARP</b>	
9-9604	CKT1	CVK-320	CKT2	PV-320/K	CKT1	CCK-310	CKT2	VC-C10UA	CKT1
9-9605	CKT1	CVK-321	CKT2	PV-400/D/DK/K	CKT1	CCK-321	CKT2	VL-L150U	CKT4
9-9606	CKT1	CVK-332	CKT1	PV-420/D/DK/K	CKT1	CPJ-810	CKT1	VL-L170U	CKT4
9-9607	CKT1	CVL-335	CKT1	PV-425	CKT1	CPK-816	CKT2	VL-L175U	CKT4
9-9608	CKT1	CVL-345	CKT1	PV-430/D/K/DK	CKT1	CPK-820	CKT2	VL-L210U	CKT4
9-9609	CKT1	VM-32/K	CKT2	PV-500/D/K/DK	CKT2	CPK-832	CKT1	VL-L270U	CKT4
9-9610	CKT1	VM-33	CKT2	PV-510/D	CKT2	<b>QUASAR</b>		VL-L280U	CKT4
CG-700	CKT1	VR-8207	CKT1	PV-515/D	CKT2	VM-10/K	CKT1	VL-L285U	CKT4
CG-710	CKT1	VR-8208	CKT1	PV-520/D/K/DK	CKT1	VM-11/K	CKT1	VL-L310U	CKT4
CG-9806	CKT1	VR-8209	CKT1	PV-530	CKT1	VM-20/K	CKT1	VL-L315U	CKT4
CG-9808	CKT1	VR-8290	CKT1	PV-535/D	CKT1	VM-20AC/ACK	CKT1	VL-L330U	CKT4
CG-9810	CKT1	VR-8291	CKT1	PV-660/D/DK/K	CKT1	VM-23/AC	CKT1	VL-L510U	CKT4
CG-9815	CKT1	VR-8292	CKT1	PV-G22M	CKT1	VM-24/AC/ACK	CKT1	VL-L4100U/C	CKT4
CG-9825	CKT1	VR-8293	CKT1	PV-S55K	CKT1	VM-25AC	CKT1	VL-L4300U	CKT4
CG-9906	CKT2	VR-8298	CKT1	PV-S440/D/K/DK	CKT1	VM-29	CKT1	VL-L8100U	CKT4
CG-9908	CKT2	VR-9294	CKT1	PV-S445/D/K/DK	CKT1	<b>SYLVANIA</b>		VCC-140	CKT1
CG-9910	CKT2	<b>PANASONIC</b>		PV-S540/D/K/DK	CKT1	VM-32/K	CKT2	VCC-141	CKT1
CG-9911	CKT2	AG-100	CKT1	PV-S550/D/K/DK	CKT1	VM-33	CKT2	VCC-150	CKT1
CG-9915	CKT2	AG-155	CKT1	PV-S575/D	CKT1	VM-34/K	CKT1	VCC-151	CKT1
CG-9920	CKT1	AG-160	CKT1	<b>PHILCO</b>		VM-35	CKT1	VCC-152	CKT1
<b>MAGNAVOX</b>		AG-170	CKT3	CPK-832AV01	CKT1	VM-37/K	CKT1	VCC-159	CKT1
CVJ-310	CKT1	AG-180U	CKT3	VCR-790	CKT1	VM-709	CKT1	VCC-161	CKT1
CVJ-320	CKT1	AG-190	CKT3	VCR-791	CKT1	<b>RCA</b>		VCC-210	CKT2
CVJ-340	CKT1	NV-M3PX	CKT1	VCR-800/SL01	CKT1	1CVA-142	CKT1	VCK-220	CKT2
CVJ-350	CKT1	NV-M5PX	CKT1	VCR-801	CKT1	CG-700	CKT1	VCK-221	CKT2
CVJ-360	CKT1	PV-200/DK/K	CKT1	VCR-802	CKT1	CG-710	CKT1	VKC-210AV01	CKT2
CVK-300	CKT2	PV-210/D/DK/K	CKT1	VCR-809	CKT1			VKC-221AV01	CKT2
CVK-310	CKT2	PV-220/D	CKT1	VKR-110	CKT2			VKC-242	CKT1

## Camcorder Heads & Cross Reference

Mfr./ Model#	CX#	Mfr./ Model#	CX#	Mfr./ Model#	CX#	Mfr./ Model#	CX#
<b>SONY</b>		CCD-F402	CX12	CCD-FX470	CX14	CCD-TR350	CX14
<b>CX8</b>	CCD-F201	CX9	CCD-F45	CX11	CCD-FX500	CX14	CCD-TR350PK
<b>CX9</b>	CCD-F280	CX11	CCD-F450	CX12	CCD-FX510	CX14	CCD-TR353
<b>CX11</b>	CCD-F288BR	CX11	CCD-F455	CX12	CCD-FX511	CX14	CCD-TR40
<b>CX12</b>	CCD-F30	CX8	CCD-F46	CX11	CCD-FX520	CX14	CCD-TR42
<b>CX14</b>	CCD-F301	CX12	CCD-F50	CX8	CCD-FX525	CX14	CCD-TR430
	CCD-F302	CX12	CCD-F55	CX12	CCD-FX530	CX14	CCD-TR50E
	CCD-F33	CX9	CCD-F56	CX12	CCD-FX600	CX14	CCD-TR550
	CCD-F330	CX8	CCD-F73	CX11	CCD-FX620	CX14	CCD-TR6
	CCD-F33PAK	CX9	CCD-FX228	CX14	CCD-FX630	CX14	CCD-TR61
	CCD-F34	CX9	CCD-FX230	CX14	CCD-M7U	CX8	CCD-TR65
	CCD-F34PAK	CX9	CCD-FX330	CX14	CCD-TR21	CX14	CCD-TR70
	CCD-F35	CX11	CCD-FX400	CX14	CCD-TR212	CX14	CCD-TR72
	CCD-F350	CX9	CCD-FX410	CX14	CCD-TR21PK	CX14	CCD-TR80
	CCD-F350PAK	CX9	CCD-FX411	CX14	CCD-TR28	CX14	CCD-TR82
	CCD-F36	CX11	CCD-FX420	CX14	CCD-TR30	CX14	CCD-TR9
	CCD-F360	CX11	CCD-FX425	CX14	CCD-TR303	CX14	CCD-TR91
	CCD-F365	CX9	CCD-FX430	CX14	CCD-TR303PK	CX14	CCD-V3/R
	CCD-F401	CX12	CCD-FX435	CX14	CCD-TR31	CX14	CCD-V30
					CCD-TR323	CX14	CCD-V4